

RSP 1570

1 Byte waveform format

Baud Rate	Parity	Valid data bits	Stop bit value	Handshaking	Data type
115200	n	8	1	none	string

1. RSP1570 -> PC

A. Display Data

Start	Count	ID	Type	Data						Chk
0xfe	0x17	0xa3	0x20	char1	...	char42	flag1	...	flag5	xx

char1~42
ASCII Characters

flag1:	flag2:	flag3:	flag4:	flag5:
bit7 Optical	bit7 Dolby Digital	bit7 PRESET	bit7 Zone	bit7 FL
bit6 Coaxial	bit6 Dolby Pro Logic	bit6 RDS	bit6 "5.1"	bit6 C
bit5 [1]	bit5 dts	bit5 Stereo (Tuner)	bit5 "7.1"	bit5 FR
bit4 [2]	bit4 ES	bit4 Tuned	bit4 ">"	bit4 SL
bit3 [3]	bit3 EX	bit3 Standby LED	bit3 "<"	bit3 SR
bit2 [4]	bit2 HDMI	bit2 Zone 2	bit2 Zone 3	bit2 SW
bit1 [5]	bit1 II	bit1 display mode1	bit1 Zone 4	bit1 SBL
bit0 [A]	bit0 x	bit0 display mode0	bit0 SB	bit0 SBR

	Normal	FL off
display mode1	0	1
display mode0	0	0

The following RS232 feedback only available after Main Software V1.2.2 installed.

B. 12V Trigger Display Data

Start	Count	ID	Type	Data					Chk
0xfe	0x07	0xa3	0x21	flag1	flag2	flag3	flag4	flag5	xx

Data	0	Off
	1	On

flag1: All Trigger	flag2: Listen Trig	flag3: Z2 Trigger	flag4: Z3 Trigger	flag5: Z4 Trigger
bit7	bit7	bit7	bit7	bit7
bit6	bit6	bit6	bit6	bit6
bit5 Trigger 6	bit5 Trigger 6	bit5 Trigger 6	bit5 Trigger 6	bit5 Trigger 6
bit4 Trigger 5	bit4 Trigger 5	bit4 Trigger 5	bit4 Trigger 5	bit4 Trigger 5
bit3 Trigger 4	bit3 Trigger 4	bit3 Trigger 4	bit3 Trigger 4	bit3 Trigger 4
bit2 Trigger 3	bit2 Trigger 3	bit2 Trigger 3	bit2 Trigger 3	bit2 Trigger 3
bit1 Trigger 2	bit1 Trigger 2	bit1 Trigger 2	bit1 Trigger 2	bit1 Trigger 2
bit0 Trigger 1	bit0 Trigger 1	bit0 Trigger 1	bit0 Trigger 1	bit0 Trigger 1

2. PC -> RSP1570

Start	Count	ID	Type	Key	Chk
0xfe	0x03	0xa3	0x10	xx	xx

key:		key:		key:		key:		key:	
0x00	RMC Vol+	0x10	Contour LF-	0x20		0x30		0x40	
0x01	RMC Vol-	0x11	Stereo	0x21		0x31		0x41	
0x02	CD	0x12	3 Stereo	0x22	Surround+	0x32		0x42	
0x03	Tuner	0x13	Pro Logic	0x23	Zone	0x33		0x43	
0x04	Tape	0x14	DSP	0x24		0x34		0x44	
0x05	Video1	0x15	5.1CH[Multi Input]	0x25		0x35		0x45	
0x06	Video2	0x16	Dynamic	0x26		0x36		0x46	
0x07	Video3	0x17	Rec	0x27		0x37		0x47	
0x08	Video4	0x18	OSD Menu	0x28		0x38		0x48	
0x09	Video5	0x19	OSD Enter	0x29		0x39		0x49	
0x0a	Power	0x1a	OSD Right(+)	0x2a		0x3a		0x4a	Power Off
0x0b	Vol+	0x1b	OSD Left(-)	0x2b		0x3b		0x4b	Power On
0x0c	Vol-	0x1c	OSD Up/Trim Sel	0x2c		0x3c		0x4c	C
0x0d	Contour HF+	0x1d	OSD Down/Dynamic	0x2d		0x3d		0x4d	S
0x0e	Contour HF-	0x1e	Mute	0x2e		0x3e		0x4e	R
0x0f	Contour LF+	0x1f	Digital In Select	0x2f		0x3f		0x4f	Filter (EQ)

key:		key:		key:		key:	
0x50		0x60	Neo:6 Music	0x70		0x93	Force Factory Default
0x51		0x61	Neo:6 Cinema	0x71	All Zones Off		
0x52	Display On/Off	0x62	PLII Music Panorama on/off toggle	0x72			
0x53	PLII / 3 Stereo	0x63	PLII Music Dimension_up [0~6]	0x73			
0x54	dtS Neo:6	0x64	PLII Music Dimension_down [0~6]	0x74	PLII Game		
0x55		0x65	PLII Music CenterWidth_up [0~7]	0x75	Output Resolution		
0x56		0x66	PLII Music CenterWidth_down [0~7]	0x76			
0x57	Music 1	0x67	Tone	0x77			
0x58	Music 2	0x68	DD EX / XS on/off	0x78	HDMI Amp Mode		
0x59	Music 3	0x69		0x79	HDMI TV Mode		
0x5a	Music 4	0x6a		0x7a			
0x5b	5 Ch Stereo	0x6b	Source	0x7b			
0x5c	7 Ch Stereo	0x6c	Mute On	0x7c			
0x5d	PLII Cinema	0x6d	Mute Off	0x7d			
0x5e	PLII Music	0x6e	Party Mode Toggle	0x7e			
0x5f		0x6f		0x7f	NULL key		
				0xff	Display Refresh		

* Requires main software V1.2.8 or later

3. PC -> RSP1570 (Direct Select Main Zone)

Start	Count	ID	Type	Key	Chk
0xfe	0x03	0xa3	0x14	xx	xx

key:		key:	
0x00	RMC Vol+	0x1e	Mute
0x01	RMC Vol-		
0x02	CD	0x4a	Power Off
0x03	Tuner	0x4b	Power On
0x04	Tape		
0x05	Video1	0x6c	Mute On
0x06	Video2	0x6d	Mute Off
0x07	Video3		
0x08	Video4	0x71	All Zones Off
0x09	Video5		
0x0a	Power		

4. PC -> RSP1570 (Direct Select Record Source)

Start	Count	ID	Type	Key	Chk
0xfe	0x03	0xa3	0x15	xx	xx

key:		key:	
0x02	CD	0x6b	Source
0x03	Tuner		
0x04	Tape		
0x05	Video1		
0x06	Video2		
0x07	Video3		
0x08	Video4		
0x09	Video5		

5. PC -> RSP1570 (Direct Select Zone 2)

Start	Count	ID	Type	Key	Chk
0xfe	0x03	0xa3	0x16	xx	xx

key:		key:	
0x00	RMC Vol+	0x4a	Zone Power Off
0x01	RMC Vol-	0x4b	Zone Power On
0x02	CD		
0x03	Tuner	0x6b	Source
0x04	Tape	0x6c	Mute On
0x05	Video1	0x6d	Mute Off
0x06	Video2	0x6e	Party Mode
0x07	Video3		
0x08	Video4	0x71	All Zones Pwr Off
0x09	Video5		
0x0a	Zone Power	0x1e	Mute

6. PC -> RSP1570 (Direct Select Zone 3)

Start	Count	ID	Type	Key	Chk
0xfe	0x03	0xa3	0x17	xx	xx

key:		key:	
0x00	RMC Vol+	0x4a	Zone Power Off
0x01	RMC Vol-	0x4b	Zone Power On
0x02	CD		
0x03	Tuner	0x6b	Source
0x04	Tape	0x6c	Mute On
0x05	Video1	0x6d	Mute Off
0x06	Video2	0x6e	Party Mode
0x07	Video3		
0x08	Video4	0x71	All Zones Pwr Off
0x09	Video5		
0x0a	Zone Power	0x1e	Mute

7. PC -> RSP1570 (Direct Select Zone 4)

Start	Count	ID	Type	Key	Chk
0xfe	0x03	0xa3	0x18	xx	xx

key:		key:	
0x00	RMC Vol+	0x4a	Zone Power Off
0x01	RMC Vol-	0x4b	Zone Power On
0x02	CD		
0x03	Tuner	0x6b	Source
0x04	Tape	0x6c	Mute On
0x05	Video1	0x6d	Mute Off
0x06	Video2	0x6e	Party Mode
0x07	Video3		
0x08	Video4	0x71	All Zones Pwr Off
0x09	Video5		
0x0a	Zone Power	0x1e	Mute

8. PC -> RSP1570 (Volume Direct)

Start	Count	ID	Type	Key	Chk
0xfe	0x03	0xa3	0x30	xx	xx

key:		key:	
0x00	volume min	0x10	volume 16
0x01	volume 1		
0x02	volume 2	0x20	volume 32
0x03	volume 3		
0x04	volume 4	0x30	volume 48
0x05	volume 5		
0x06	volume 6	0x40	volume 64
0x07	volume 7		
0x08	volume 8	0x50	volume 80
0x09	volume 9		
0x0a	volume 10	0x5f	volume 95
0x0b	volume 11	0x64	volume max
0x0c	volume 12		
0x0d	volume 13		
0x0e	volume 14		
0x0f	volume 15		

9. PC -> RSP1570 (Volume Direct Zone 2)

Start	Count	ID	Type	Key	Chk
0xfe	0x03	0xa3	0x32	xx	xx

key:		key:	
0x00	volume min	0x10	volume 16
0x01	volume 1		
0x02	volume 2	0x20	volume 32
0x03	volume 3		
0x04	volume 4	0x30	volume 48
0x05	volume 5		
0x06	volume 6	0x40	volume 64
0x07	volume 7		
0x08	volume 8	0x50	volume 80
0x09	volume 9		
0x0a	volume 10	0x5f	volume 95
0x0b	volume 11	0x60	volume max
0x0c	volume 12		
0x0d	volume 13		
0x0e	volume 14		
0x0f	volume 15		

10. PC -> RSP1570 (Volume Direct Zone 3)

Start	Count	ID	Type	Key	Chk
0xfe	0x03	0xa3	0x33	xx	xx

key:		key:	
0x00	volume min	0x10	volume 16
0x01	volume 1		
0x02	volume 2	0x20	volume 32
0x03	volume 3		
0x04	volume 4	0x30	volume 48
0x05	volume 5		
0x06	volume 6	0x40	volume 64
0x07	volume 7		
0x08	volume 8	0x50	volume 80
0x09	volume 9		
0x0a	volume 10	0x59	volume 89
0x0b	volume 11	0x60	volume max
0x0c	volume 12		
0x0d	volume 13		
0x0e	volume 14		
0x0f	volume 15		

11. PC -> RSP1570 (Volume Direct Zone 4)

Start	Count	ID	Type	Key	Chk
0xfe	0x03	0xa3	0x34	xx	xx

key:		key:	
0x00	volume min	0x10	volume 16
0x01	volume 1		
0x02	volume 2	0x20	volume 32
0x03	volume 3		
0x04	volume 4	0x30	volume 48
0x05	volume 5		
0x06	volume 6	0x40	volume 64
0x07	volume 7		
0x08	volume 8	0x50	volume 80
0x09	volume 9		
0x0a	volume 10	0x59	volume 89
0x0b	volume 11	0x60	volume max
0x0c	volume 12		
0x0d	volume 13		
0x0e	volume 14		
0x0f	volume 15		

The following RS232 commands only available after Main Software V1.2.2 installed.

12. PC -> RSP1570 (12V Trigger Direct)

Start	Count	ID	Type	Key	Chk
0xfe	0x03	0xa3	0x40	xx	xx

key:		key:	
0x00	Listen Trigger 1	0x10	Zone 3 Trigger 5
0x01	Listen Trigger 2	0x11	Zone 3 Trigger 6
0x02	Listen Trigger 3	0x12	Zone 4 Trigger 1
0x03	Listen Trigger 4	0x13	Zone 4 Trigger 2
0x04	Listen Trigger 5	0x14	Zone 4 Trigger 3
0x05	Listen Trigger 6	0x15	Zone 4 Trigger 4
0x06	Zone 2 Trigger 1	0x16	Zone 4 Trigger 5
0x07	Zone 2 Trigger 2	0x17	Zone 4 Trigger 6
0x08	Zone 2 Trigger 3		
0x09	Zone 2 Trigger 4		
0x0a	Zone 2 Trigger 5		
0x0b	Zone 2 Trigger 6		
0x0c	Zone 3 Trigger 1		
0x0d	Zone 3 Trigger 2		
0x0e	Zone 3 Trigger 3		
0x0f	Zone 3 Trigger 4		

RSP 1570 RS232 Controller Command List

Table: RSP 1570 Waveform format expected:

Baud Rate	Parity	Valid Data Bits	Stop Bit Value	Handshaking	Data Type
115200	N	8	1	None	String

Table: RSP 1570 expected format of a request by RS232 controller:

Start	Count	Device ID	Type	Key	Checksum
0xFE	0x03	0xA3	0x10	0xFF	0xFF

Table 1: Type 10 Primary Command List

NOTE: The values in the table below show the exact byte sequence of all requests. The device will expect the bytes only - no spaces, no delimiter, etc. The controlling device may implement its own method to download each command sequence. The numerical values in the first column are Hexadecimal.

RSP 1570 HEX	Command	Command Description
FE 03 A3 10 02 B8	CD	Source CD
FE 03 A3 10 03 B9	Tuner	Source Tuner
FE 03 A3 10 04 BA	Tape	Source Tape
FE 03 A3 10 05 BB	Video 1	Source Video 1
FE 03 A3 10 06 BC	Video 2	Source Video 2
FE 03 A3 10 07 BD	Video 3	Source Video 3
FE 03 A3 10 08 BE	Video 4	Source Video 4
FE 03 A3 10 09 BF	Video 5	Source Video 5
FE 03 A3 10 0A C0	Power	Power Toggle
FE 03 A3 10 0B C1	Vol+	Volume Up
FE 03 A3 10 0C C2	Vol-	Volume Down
FE 03 A3 10 0D C3	Treble+	Treble Up
FE 03 A3 10 0E C4	Treble-	Treble Down
FE 03 A3 10 0F C5	Bass+	Bass Up
FE 03 A3 10 10 C6	Bass-	Bass Down
FE 03 A3 10 11 C7	Stereo	Stereo / Bypass Toggle
FE 03 A3 10 12 C8	3 Stereo	Dolby 3 Stereo
FE 03 A3 10 13 C9	Pro Logic	Dolby PLIIx Mode Toggle
FE 03 A3 10 14 CA	DSP	DSP 1-4/5CH/7CH Toggle
FE 03 A3 10 15 CB	Multi	Multi Input
FE 03 A3 10 16 CC	Dynamic	Dynamic Range
FE 03 A3 10 17 CD	Rec	Record
FE 03 A3 10 18 CE	OSD Menu	OSD Menu
FE 03 A3 10 19 CF	OSD Enter	OSD Enter
FE 03 A3 10 1A D0	OSD Right (+)	OSD Right
FE 03 A3 10 1B D1	OSD Left (-)	OSD Left
FE 03 A3 10 1C D2	OSD Up	OSD Up
FE 03 A3 10 1D D3	OSD Down / Dynamic	OSD Down / Dynamic
FE 03 A3 10 1E D4	Mute	Mute

RSP 1570 HEX	Command	Command Description
FE 03 A3 10 1F D5	Digital In Select	Digital Input Select
FE 03 A3 10 22 D8	Surround+	Next Surround Mode
FE 03 A3 10 23 D9	Zone 2 / Main	Zone
FE 03 A3 10 4A 00	Power Off	Power Off
FE 03 A3 10 4B 01	Power On	Power On
FE 03 A3 10 4C 02	C	Center
FE 03 A3 10 4D 03	S	Subwoofer
FE 03 A3 10 4E 04	R	Surround
FE 03 A3 10 4F 05	Filter (EQ)	Cinema EQ
FE 03 A3 10 52 08	FL On / Off	FL Display Toggle
FE 03 A3 10 53 09	Pro Logic / 3 Stereo	Dolby 3 Stereo / PLIIx Toggle
FE 03 A3 10 54 0A	dts Neo:6	dts Neo:6 Music/Cinema Toggle
FE 03 A3 10 57 0D	DSP 1	DSP 1
FE 03 A3 10 58 0E	DSP 2	DSP 2
FE 03 A3 10 59 0F	DSP 3	DSP 3
FE 03 A3 10 5A 10	DSP 4	DSP 4
FE 03 A3 10 5B 11	5Ch Stereo	5Ch Stereo
FE 03 A3 10 5C 12	7Ch Stereo	7Ch Stereo
FE 03 A3 10 5D 13	PLIIx Cinema	Dolby PLIIx Cinema
FE 03 A3 10 5E 14	PLIIx Music	Dolby PLIIx Music
FE 03 A3 10 5F 15	Dolby Pro Logic	Dolby Pro Logic
FE 03 A3 10 60 16	dts Neo:6 Music	dts Neo:6 Music
FE 03 A3 10 61 17	dts Neo:6 Cinema	dts Neo:6 Cinema
FE 03 A3 10 62 18	PLIIx Panorama	PLIIx Panorama
FE 03 A3 10 63 19	PLIIx Dimension Up	PLIIx Dimension Up
FE 03 A3 10 64 1A	PLIIx Dimension Down	PLIIx Dimension Down
FE 03 A3 10 65 1B	PLIIx Center Width Up	PLIIx Center Width Up
FE 03 A3 10 66 1C	PLIIx Center Width Down	PLIIx Center Width Down
FE 03 A3 10 67 1D	Shift (Treble Bass)	Tone Controls
FE 03 A3 10 68 1E	DD EX On/Off	DD EX On/Off
FE 03 A3 10 6E 24	Party Mode	Party Mode Toggle
FE 03 A3 10 71 27	All Zones Off	Power Off All Zones
FE 03 A3 10 74 2A	PLIIx Game	Dolby PLIIx Game
FE 03 A3 10 75 2B	Output Resolution	Output Resolution
FE 03 A3 10 78 2E	HDMI Amp Mode	HDMI Amp Mode
FE 03 A3 10 79 2F	HDMI TV Mode	HDMI TV Mode
FE 03 A3 10 7C 32	HDMI Bypass Off	HDMI Bypass Off
FE 03 A3 10 7D 33	HDMI Bypass On	HDMI Bypass On
FE 03 A3 10 93 49	Factory Default	Force Factory Default
FE 03 A3 10 FF B5	Display Refresh	Display Refresh

* Requires main software V1.2.8.

Table 2: Type 14 Main Zone Command List

It is recommended for multi zone applications that these commands be used for main zone control instead of the type 10 commands above to avoid any potential conflicts with remote zone control.

RSP 1570 HEX	Command	Command Description
FE 03 A3 14 00 BA	Vol+	Main Zone Volume Up
FE 03 A3 14 01 BB	Vol-	Main Zone Volume Down
FE 03 A3 14 02 BC	Main CD	Main Zone Source CD
FE 03 A3 14 03 BD	Main Tuner	Main Zone Source Tuner
FE 03 A3 14 04 BE	Main Tape	Main Zone Source Tape
FE 03 A3 14 05 BF	Main Video 1	Main Zone Source Video 1
FE 03 A3 14 06 C0	Main Video 2	Main Zone Source Video 2
FE 03 A3 14 07 C1	Main Video 3	Main Zone Source Video 3
FE 03 A3 14 08 C2	Main Video 4	Main Zone Source Video 4
FE 03 A3 14 09 C3	Main Video 5	Main Zone Source Video 5
FE 03 A3 14 0A C4	Main Power	Main Zone Power Toggle
FE 03 A3 14 1E D8	Main Mute	Main Zone Mute
FE 03 A3 14 4A 04	Main Power Off	Main Zone Power Off
FE 03 A3 14 4B 05	Main Power On	Main Zone Power On
FE 03 A3 14 6C 26	Main Mute On	Main Zone Mute On
FE 03 A3 14 6D 27	Main Mute Off	Main Zone Mute Off

Table 3: Type 15 Record Source Command List

RSP 1570 HEX	Command	Command Description
FE 03 A3 15 02 BD	Record CD	Record Source CD
FE 03 A3 15 03 BE	Record Tuner	Record Source Tuner
FE 03 A3 15 04 BF	Record Tape	Record Source Tape
FE 03 A3 15 05 C0	Record Video 1	Record Source Video 1
FE 03 A3 15 06 C1	Record Video 2	Record Source Video 2
FE 03 A3 15 07 C2	Record Video 3	Record Source Video 3
FE 03 A3 15 08 C3	Record Video 4	Record Source Video 4
FE 03 A3 15 09 C4	Record Video 5	Record Source Video 5
FE 03 A3 15 6B 26	Record Source	Record Source

Table 4: Type 16 Zone 2 Command List

RSP 1570 HEX	Command	Command Description
FE 03 A3 16 00 BC	Vol+	Zone 2 Volume Up
FE 03 A3 16 01 BD	Vol-	Zone 2 Volume Down
FE 03 A3 16 02 BE	Zone 2 CD	Zone 2 Source CD
FE 03 A3 16 03 BF	Zone 2 Tuner	Zone 2 Source Tuner
FE 03 A3 16 04 C0	Zone 2 Tape	Zone 2 Source Tape
FE 03 A3 16 05 C1	Zone 2 Video 1	Zone 2 Source Video 1
FE 03 A3 16 06 C2	Zone 2 Video 2	Zone 2 Source Video 2
FE 03 A3 16 07 C3	Zone 2 Video 3	Zone 2 Source Video 3
FE 03 A3 16 08 C4	Zone 2 Video 4	Zone 2 Source Video 4

RSP 1570 HEX	Command	Command Description
FE 03 A3 16 09 C5	Zone 2 Video 5	Zone 2 Source Video 5
FE 03 A3 16 0A C6	Zone 2 Power	Zone 2 Power Toggle
FE 03 A3 16 1E DA	Zone 2 Mute	Zone 2 Mute Toggle
FE 03 A3 16 4A 06	Zone 2 Power Off	Zone 2 Power Off
FE 03 A3 16 4B 07	Zone 2 Power On	Zone 2 Power On
FE 03 A3 16 6B 27	Zone 2 Source	Zone 2 Source
FE 03 A3 16 6C 28	Zone 2 Mute On	Zone 2 Mute On
FE 03 A3 16 6D 29	Zone 2 Mute Off	Zone 2 Mute Off
FE 03 A3 16 6E 2A	Party Mode	Party Mode Toggle
FE 03 A3 16 71 2D	All Zones Off	Power Off All Zones

Table 5: Type 17 Zone 3 Command List

RSP 1570 HEX	Command	Command Description
FE 03 A3 17 00 BD	Vol+	Zone 3 Volume Up
FE 03 A3 17 01 BE	Vol-	Zone 3 Volume Down
FE 03 A3 17 02 BF	Zone 3 CD	Zone 3 Source CD
FE 03 A3 17 03 C0	Zone 3 Tuner	Zone 3 Source Tuner
FE 03 A3 17 04 C1	Zone 3 Tape	Zone 3 Source Tape
FE 03 A3 17 05 C2	Zone 3 Video 1	Zone 3 Source Video 1
FE 03 A3 17 06 C3	Zone 3 Video 2	Zone 3 Source Video 2
FE 03 A3 17 07 C4	Zone 3 Video 3	Zone 3 Source Video 3
FE 03 A3 17 08 C5	Zone 3 Video 4	Zone 3 Source Video 4
FE 03 A3 17 09 C6	Zone 3 Video 5	Zone 3 Source Video 5
FE 03 A3 17 0A C7	Zone 3 Power	Zone 3 Power Toggle
FE 03 A3 17 1E DB	Zone 3 Mute	Zone 3 Mute Toggle
FE 03 A3 17 4A 07	Zone 3 Power Off	Zone 3 Power Off
FE 03 A3 17 4B 08	Zone 3 Power On	Zone 3 Power On
FE 03 A3 17 6B 28	Zone 3 Source	Zone 3 Source
FE 03 A3 17 6C 29	Zone 3 Mute On	Zone 3 Mute On
FE 03 A3 17 6D 2A	Zone 3 Mute Off	Zone 3 Mute Off
FE 03 A3 17 6E 2B	Party Mode	Party Mode Toggle
FE 03 A3 17 71 2E	All Zones Off	Power Off All Zones

Table 6: Type 18 Zone 4 Command List

RSP 1570 HEX	Command	Command Description
FE 03 A3 18 00 BE	Vol+	Zone 4 Volume Up
FE 03 A3 18 01 BF	Vol-	Zone 4 Volume Down
FE 03 A3 18 02 C0	Zone 4 CD	Zone 4 Source CD
FE 03 A3 18 03 C1	Zone 4 Tuner	Zone 4 Source Tuner
FE 03 A3 18 04 C2	Zone 4 Tape	Zone 4 Source Tape
FE 03 A3 18 05 C3	Zone 4 Video 1	Zone 4 Source Video 1
FE 03 A3 18 06 C4	Zone 4 Video 2	Zone 4 Source Video 2
FE 03 A3 18 07 C5	Zone 4 Video 3	Zone 4 Source Video 3
FE 03 A3 18 08 C6	Zone 4 Video 4	Zone 4 Source Video 4
FE 03 A3 18 09 C7	Zone 4 Video 5	Zone 4 Source Video 5
FE 03 A3 18 0A C8	Zone 4 Power	Zone 4 Power Toggle

RSP 1570 HEX	Command	Command Description
FE 03 A3 18 1E DC	Zone 4 Mute	Zone 4 Mute Toggle
FE 03 A3 18 4A 08	Zone 4 Power Off	Zone 4 Power Off
FE 03 A3 18 4B 09	Zone 4 Power On	Zone 4 Power On
FE 03 A3 18 6B 29	Zone 4 Source	Zone 4 Source
FE 03 A3 18 6C 2A	Zone 4 Mute On	Zone 4 Mute On
FE 03 A3 18 6D 2B	Zone 4 Mute Off	Zone 4 Mute Off
FE 03 A3 18 6E 2C	Party Mode	Party Mode Toggle
FE 03 A3 18 71 2F	All Zones Off	Power Off All Zones

Table 7: Type 30 Volume Direct Command List

RSP 1570 HEX	Command	Command Description
FE 03 A3 30 00 D6	Volume Min	Volume Min
FE 03 A3 30 01 D7	Volume 1	Volume 1
FE 03 A3 30 02 D8	Volume 2	Volume 2
FE 03 A3 30 03 D9	Volume 3	Volume 3
FE 03 A3 30 04 DA	Volume 4	Volume 4
FE 03 A3 30 05 DB	Volume 5	Volume 5
FE 03 A3 30 06 DC	Volume 6	Volume 6
FE 03 A3 30 07 DD	Volume 7	Volume 7
FE 03 A3 30 08 DE	Volume 8	Volume 8
FE 03 A3 30 09 DF	Volume 9	Volume 9
FE 03 A3 30 0A E0	Volume 10	Volume 10
FE 03 A3 30 0B E1	Volume 11	Volume 11
FE 03 A3 30 0C E2	Volume 12	Volume 12
FE 03 A3 30 0D E3	Volume 13	Volume 13
FE 03 A3 30 0E E4	Volume 14	Volume 14
FE 03 A3 30 0F E5	Volume 15	Volume 15
FE 03 A3 30 10 E6	Volume 16	Volume 16
FE 03 A3 30 20 F6	Volume 32	Volume 32
FE 03 A3 30 30 06	Volume 48	Volume 48
FE 03 A3 30 40 16	Volume 64	Volume 64
FE 03 A3 30 50 26	Volume 80	Volume 80
FE 03 A3 30 5F 35	Volume 95	Volume 95
FE 03 A3 30 60 36	Volume Max	Volume Max

Table 7A: Commands Sent with exceptions or modifications required

RSP 1570 HEX	Command Expected	Command
FE 03 A3 30 27 FD	FE 03 A3 30 27 FD 00	Volume 39
FE 03 A3 30 28 FE	FE 03 A3 30 28 FD 01	Volume 40

The table above list commands with exceptions. To keep the RSP 1570 from encountering the start byte FE in any position other than as the start byte, any occurrence of the bytes FE or FD in the command string must be converted to either FD 00 (for FD) or FD 01 (for FE). This will allow the string to pass while masking any occurrence of the byte FE except as the start byte.

Table 8: Type 32 Zone 2 Volume Direct Command List

RSP 1570 HEX	Command	Command Description
FE 03 A3 32 00 D8	Zone 2 Volume Min	Zone 2 Volume Min
FE 03 A3 32 01 D9	Zone 2 Volume 1	Zone 2 Volume 1
FE 03 A3 32 02 DA	Zone 2 Volume 2	Zone 2 Volume 2
FE 03 A3 32 03 DB	Zone 2 Volume 3	Zone 2 Volume 3
FE 03 A3 32 04 DC	Zone 2 Volume 4	Zone 2 Volume 4
FE 03 A3 32 05 DD	Zone 2 Volume 5	Zone 2 Volume 5
FE 03 A3 32 06 DE	Zone 2 Volume 6	Zone 2 Volume 6
FE 03 A3 32 07 DF	Zone 2 Volume 7	Zone 2 Volume 7
FE 03 A3 32 08 E0	Zone 2 Volume 8	Zone 2 Volume 8
FE 03 A3 32 09 E1	Zone 2 Volume 9	Zone 2 Volume 9
FE 03 A3 32 0A E2	Zone 2 Volume 10	Zone 2 Volume 10
FE 03 A3 32 0B E3	Zone 2 Volume 11	Zone 2 Volume 11
FE 03 A3 32 0C E4	Zone 2 Volume 12	Zone 2 Volume 12
FE 03 A3 32 0D E5	Zone 2 Volume 13	Zone 2 Volume 13
FE 03 A3 32 0E E6	Zone 2 Volume 14	Zone 2 Volume 14
FE 03 A3 32 0F E7	Zone 2 Volume 15	Zone 2 Volume 15
FE 03 A3 32 10 E8	Zone 2 Volume 16	Zone 2 Volume 16
FE 03 A3 32 20 F8	Zone 2 Volume 32	Zone 2 Volume 32
FE 03 A3 32 30 08	Zone 2 Volume 48	Zone 2 Volume 48
FE 03 A3 32 40 18	Zone 2 Volume 64	Zone 2 Volume 64
FE 03 A3 32 50 28	Zone 2 Volume 80	Zone 2 Volume 80
FE 03 A3 32 5F 37	Zone 2 Volume 95	Zone 2 Volume 95
FE 03 A3 32 60 38	Zone 2 Volume Max	Zone 2 Volume Max

Table 8A: Commands Sent with exceptions or modifications required

RSP 1570 HEX	Command Expected	Command
FE 03 A3 32 25 FD	FE 03 A3 32 25 FD 00	Zone 2 Volume 37
FE 03 A3 32 26 FE	FE 03 A3 32 26 FD 01	Zone 2 Volume 38

The table above list commands with exceptions. To keep the RSP 1570 from encountering the start byte FE in any position other than as the start byte, any occurrence of the bytes FE or FD in the command string must be converted to either FD 00 (for FD) or FD 01 (for FE). This will allow the string to pass while masking any occurrence of the byte FE except as the start byte.

Table 9: Type 33 Zone 3 Volume Direct Command List

RSP 1570 HEX	Command	Command Description
FE 03 A3 33 00 D9	Zone 3 Volume Min	Zone 3 Volume Min
FE 03 A3 33 01 DA	Zone 3 Volume 1	Zone 3 Volume 1
FE 03 A3 33 02 DB	Zone 3 Volume 2	Zone 3 Volume 2
FE 03 A3 33 03 DC	Zone 3 Volume 3	Zone 3 Volume 3
FE 03 A3 33 04 DD	Zone 3 Volume 4	Zone 3 Volume 4
FE 03 A3 33 05 DE	Zone 3 Volume 5	Zone 3 Volume 5
FE 03 A3 33 06 DF	Zone 3 Volume 6	Zone 3 Volume 6
FE 03 A3 33 07 E0	Zone 3 Volume 7	Zone 3 Volume 7
FE 03 A3 33 08 E1	Zone 3 Volume 8	Zone 3 Volume 8

RSP 1570 HEX	Command	Command Description
FE 03 A3 33 09 E2	Zone 3 Volume 9	Zone 3 Volume 9
FE 03 A3 33 0A E3	Zone 3 Volume 10	Zone 3 Volume 10
FE 03 A3 33 0B E4	Zone 3 Volume 11	Zone 3 Volume 11
FE 03 A3 33 0C E5	Zone 3 Volume 12	Zone 3 Volume 12
FE 03 A3 33 0D E6	Zone 3 Volume 13	Zone 3 Volume 13
FE 03 A3 33 0E E7	Zone 3 Volume 14	Zone 3 Volume 14
FE 03 A3 33 0F E8	Zone 3 Volume 15	Zone 3 Volume 15
FE 03 A3 33 10 E9	Zone 3 Volume 16	Zone 3 Volume 16
FE 03 A3 33 20 F9	Zone 3 Volume 32	Zone 3 Volume 32
FE 03 A3 33 30 09	Zone 3 Volume 48	Zone 3 Volume 48
FE 03 A3 33 40 19	Zone 3 Volume 64	Zone 3 Volume 64
FE 03 A3 33 50 29	Zone 3 Volume 80	Zone 3 Volume 80
FE 03 A3 33 5F 38	Zone 3 Volume 95	Zone 3 Volume 95
FE 03 A3 33 60 39	Zone 3 Volume Max	Zone 3 Volume Max

Table 9A: Commands Sent with exceptions or modifications required

RSP 1570 HEX	Command Expected	Command
FE 03 A3 33 24 FD	FE 03 A3 33 24 FD 00	Zone 3 Volume 36
FE 03 A3 33 25 FE	FE 03 A3 33 25 FD 01	Zone 3 Volume 37

The table above list commands with exceptions. To keep the RSP 1570 from encountering the start byte FE in any position other than as the start byte, any occurrence of the bytes FE or FD in the command string must be converted to either FD 00 (for FD) or FD 01 (for FE). This will allow the string to pass while masking any occurrence of the byte FE except as the start byte.

Table 10: Type 34 Zone 4 Volume Direct Command List

RSP 1570 HEX	Command	Command Description
FE 03 A3 34 00 DA	Zone 4 Volume Min	Zone 4 Volume Min
FE 03 A3 34 01 DB	Zone 4 Volume 1	Zone 4 Volume 1
FE 03 A3 34 02 DC	Zone 4 Volume 2	Zone 4 Volume 2
FE 03 A3 34 03 DD	Zone 4 Volume 3	Zone 4 Volume 3
FE 03 A3 34 04 DE	Zone 4 Volume 4	Zone 4 Volume 4
FE 03 A3 34 05 DF	Zone 4 Volume 5	Zone 4 Volume 5
FE 03 A3 34 06 E0	Zone 4 Volume 6	Zone 4 Volume 6
FE 03 A3 34 07 E1	Zone 4 Volume 7	Zone 4 Volume 7
FE 03 A3 34 08 E2	Zone 4 Volume 8	Zone 4 Volume 8
FE 03 A3 34 09 E3	Zone 4 Volume 9	Zone 4 Volume 9
FE 03 A3 34 0A E4	Zone 4 Volume 10	Zone 4 Volume 10
FE 03 A3 34 0B E5	Zone 4 Volume 11	Zone 4 Volume 11
FE 03 A3 34 0C E6	Zone 4 Volume 12	Zone 4 Volume 12
FE 03 A3 34 0D E7	Zone 4 Volume 13	Zone 4 Volume 13
FE 03 A3 34 0E E8	Zone 4 Volume 14	Zone 4 Volume 14
FE 03 A3 34 0F E9	Zone 4 Volume 15	Zone 4 Volume 15
FE 03 A3 34 10 EA	Zone 4 Volume 16	Zone 4 Volume 16
FE 03 A3 34 20 FA	Zone 4 Volume 32	Zone 4 Volume 32
FE 03 A3 34 30 0A	Zone 4 Volume 48	Zone 4 Volume 48
FE 03 A3 34 40 1A	Zone 4 Volume 64	Zone 4 Volume 64

RSP 1570 HEX	Command Expected	Command
FE 03 A3 34 50 2A	Zone 4 Volume 80	Zone 4 Volume 80
FE 03 A3 34 50 39	Zone 4 Volume 95	Zone 4 Volume 95
FE 03 A3 34 50 3A	Zone 4 Volume Max	Zone 4 Volume Max

Table 10A: Commands Sent with exceptions or modifications required

RSP 1570 HEX	Command Expected	Command
FE 03 A3 34 23 FD	FE 03 A3 34 23 FD 00	Zone 4 Volume 35
FE 03 A3 34 24 FE	FE 03 A3 34 24 FD 01	Zone 4 Volume 36

The table above list commands with exceptions. To keep the RSP 1570 from encountering the start byte FE in any position other than as the start byte, any occurrence of the bytes FE or FD in the command string must be converted to either FD 00 (for FD) or FD 01 (for FE). This will allow the string to pass while masking any occurrence of the byte FE except as the start byte.

Table 11: Type 40 12V Trigger Direct Command List

The commands below require Main Software V1.2.2 to be installed on the unit to be effective.

RSP 1570 HEX	Command	Command Description
FE 03 A3 40 00 E6	Listen Trigger 1	Listen 12V Trigger 1 Toggle
FE 03 A3 40 01 E7	Listen Trigger 2	Listen 12V Trigger 2 Toggle
FE 03 A3 40 02 E8	Listen Trigger 3	Listen 12V Trigger 3 Toggle
FE 03 A3 40 03 E9	Listen Trigger 4	Listen 12V Trigger 4 Toggle
FE 03 A3 40 04 EA	Listen Trigger 5	Listen 12V Trigger 5 Toggle
FE 03 A3 40 05 EB	Listen Trigger 6	Listen 12V Trigger 6 Toggle
FE 03 A3 40 06 EC	Zone 2 Trigger 1	Zone 2 12V Trigger 1 Toggle
FE 03 A3 40 07 ED	Zone 2 Trigger 2	Zone 2 12V Trigger 2 Toggle
FE 03 A3 40 08 EE	Zone 2 Trigger 3	Zone 2 12V Trigger 3 Toggle
FE 03 A3 40 09 EF	Zone 2 Trigger 4	Zone 2 12V Trigger 4 Toggle
FE 03 A3 40 0A F0	Zone 2 Trigger 5	Zone 2 12V Trigger 5 Toggle
FE 03 A3 40 0B F1	Zone 2 Trigger 6	Zone 2 12V Trigger 6 Toggle
FE 03 A3 40 0C F2	Zone 3 Trigger 1	Zone 3 12V Trigger 1 Toggle
FE 03 A3 40 0D F3	Zone 3 Trigger 2	Zone 3 12V Trigger 2 Toggle
FE 03 A3 40 0E F4	Zone 3 Trigger 3	Zone 3 12V Trigger 3 Toggle
FE 03 A3 40 0F F5	Zone 3 Trigger 4	Zone 3 12V Trigger 4 Toggle
FE 03 A3 40 10 F6	Zone 3 Trigger 5	Zone 3 12V Trigger 5 Toggle
FE 03 A3 40 11 F7	Zone 3 Trigger 6	Zone 3 12V Trigger 6 Toggle
FE 03 A3 40 12 F8	Zone 4 Trigger 1	Zone 4 12V Trigger 1 Toggle
FE 03 A3 40 13 F9	Zone 4 Trigger 2	Zone 4 12V Trigger 2 Toggle
FE 03 A3 40 14 FA	Zone 4 Trigger 3	Zone 4 12V Trigger 3 Toggle
FE 03 A3 40 15 FB	Zone 4 Trigger 4	Zone 4 12V Trigger 4 Toggle
FE 03 A3 40 16 FC	Zone 4 Trigger 5	Zone 4 12V Trigger 5 Toggle
FE 03 A3 40 17 FD	Zone 4 Trigger 6	Zone 4 12V Trigger 6 Toggle

Table 11A: Commands Sent with exceptions or modifications required

RSP 1570 HEX	Command Expected	Command
FE 03 A3 40 17 FD	FE 03 A3 40 17 FD 00	Zone 4 Trigger 6